ROMAN BLIND MOTOR PROGRAMMING FLOWCHART

* Do not press DOWN button at this stage. Always set the upper limit first. This ensures that the system remembers the fully released position of the blind for the lower limit setting. If the DOWN button is pressed before upper limit setting, then the blind will not stop automatically when it reaches its fully released position during lower limit setting (as indicated in Step 7 in user instructions).